

PARTS LIST

No.	Description	Qty
1	Right Housing	1
2	Screw,ST3.5 x15C	8
3	Screw,ST3.5 X18C	4
4	Circlip,10.9	1
5	Washer,15.3/12.3	1
6	Spring	1
7	Sliding sleeve	1
8	Gearbox	1
9	washer	1
10	Steel ball Φ 3	2
11	Output shaft	1
12	Impact Assy	1
13	Bearing,6800Z	1
14	Back cover	1
15	Solar disc-2	1

No.	Description	Qty
16	Ring gear	1
17	Solar disc-1	1
18	Planetary gear	8
19	Washer	1
20	Screw,M3X6	2
21	Motor gear	1
22	Bracket	1
23	Motor,12V	1
24	Damping rubber boot	1
25	Positive inversion Lever	1
26	Left Housing	1
27	Switch	1
28	Chassis contact sheet	1
29	Charger	1
30	Battery pack	1

ASSEMBLY DIAGRAM

