

PARTS LIST

Part	Description	Qty.	Part	Description	Qty.
1	Blow suction push button	1	30	Retaining ring	1
2	Cross recessed pan headtapping screw	12	31	Reciprocating rod roller	1
3	Housing	1	32	Gear gasket	1
4	Protective minrror	1	33	Gearwheel	1
5	Blow-suction baffle	1	34	Counter balance	1
6	Socket head screw	2	35	Blade-lifting plate	1
7	Connecting plate	1	36	Needle bearing	1
8	Lift tool post pin	1	37	Bearing holder	1
9	Eccentric block	1	38	Base plate component	1
10	Gasket	2	39	Retaining plate	1
11	Saw bracket assembly	1	40	Cross recessed pan headtapping screw	2
12	Knife lifting knob gasket	1	41	629 bearing	1
13	Knife lift knob $\phi 6$ circlip	1	42	Dust suction pipe	1
14	Knife lifting knob gasket	1	43	Rotor	1
15	Steel ball S	1	44	Carbon brush	2
16	Knob spring	1	45	Brush box	2
17	Knife lifting knob	1	46	607 bearing	1
18	Protective steel wire	1	47	stator	1
19	Spring cap	1	48	Inductance	2
20	Plunger holder spring	1	49	Hexagon wrench	1
21	Reciprocating rod component(quick assembly)	1	50	Cable & plug	1
22	Reciprocating rod gasket	2	51	Cable guard	1
23	Pin	2	52	Binding post	1
24	PCB Board	1	53	Switch component	1
25	LED tube	1	54	Switch lock lever	1
26	Cross recessed pan headtapping screw	1	55	Left and right lock return spring	1
27	Laser button	1	56	PCB	1
28	Laser switch	1	57	Screw	
29	Laser circuit board	1			

ASSEMBLY DIAGRAM

